

# MONTAGEANLEITUNG

## KENNZEICHENHALTER – MTP22485

### DE

- Entfernen Sie den Sitz und senken Sie den Kennzeichenhalter-Unterboden ab. Ziehen Sie anschließend die Steckerbuchse der Kennzeichenbeleuchtung ab.
- Entfernen Sie vorübergehend den Tankdeckel um die Heckverkleidung abzunehmen und trennen Sie die Steckverbindungen für Rücklicht und Blinker. Bitte markieren Sie die entsprechenden Anschlüsse, um den erneuten Zusammenbau zu erleichtern!
- Entfernen Sie die Original-Kennzeichenhalterung und montieren Sie die Blinker (an ❶) und das Rücklicht an der neuen Halterung. Schützen Sie die Verkabelung mit dem mitgelieferten Schrumpfschlauch.
- Setzen Sie den neuen Kennzeichenhalter unten am Heck an und befestigen Sie ihn seitlich ❷ mit je einer M6 Schraube und Unterlegscheibe.
- Schließen Sie die Steckverbindungen für Rücklicht und Blinker an.
- Entfernen Sie noch einmal kurz den Tankdeckel um die hintere Verkleidung wieder zu montieren.
- Bringen Sie den Kennzeichenhalter in Position und fixieren ihn von unten ❸ mit zwei Schrauben inkl. Unterlegscheibe.



### ENG

- Remove the seat and lower the license plate bracket under-tray. Afterwards disconnect the license plate illuminator plug socket.
- Temporarily remove the fuel cap to remove the rear cowl and disconnect the rear light and indicator plug sockets. Please mark the appropriate connections to facilitate reassembly!
- Remove the original licence plate bracket and mount the indicators (at ❶) and the rear light on the new one. Protect the wirings with provided heat shrink.
- Place the new licence plate holder at the bottom of the tail and fasten it laterally ❷ with one M6 bolt and washer each.
- Reconnect the rear light and indicator plug sockets.
- Temporarily remove the fuel cap again, to reassemble the rear cowl.
- Push the licence plate holder into position and fix it from below ❸ with two bolts incl washer.



**mtp-racing GmbH**

Zornedinger Straße 19 ■ DE-5614 Kirchseeon OT Buch  
mtp-racing.de ■ info@mtp-racing.de ■ +49 8091 5628500